




EN: This Datasheet/Document is presented by the manufacturer.

Please visit our website for pricing and availability at www.hestore.hu.

DIGITAL MICROSCOPE



CONTENTS

English.....	01-11
German.....	12-22
Italian.....	23-33
French.....	34-44
Spanish.....	45-55
Japanese.....	56-66
Chinese.....	67-77


PREFACE

Thank you for purchasing this device. This product is complex to use, so please read this manual in detail to understand how to operate the microscope before using it.

IMPORTANT NOTES

1. Please fully charge the device before first use. Do not charge directly via the PC. Please choose the 5V 1A adapter.
2. For the first use, please format the memory card.
3. This product does not require adjusting the focal length. When using it, the surface of the object to be observed must be flat to achieve a clear image.
4. This device cannot accurately read the microscope magnification. It is a combination of digital and optical magnification microscope, the specific magnification effect is subject to the actual picture taken.
5. Please do not touch the lens and other optical parts with your hands, as this may result in blurred images and affect the image quality.
6. Do not disassemble the product or its components to avoid abnormal use of the device.

PRODUCT DESCRIPTION



BUTTON FUNCTIONS EXPLAINED

Power Button (Power On/Off/Confirm)

While powered off, long press "Power On"

In any interface, long press "Power Off"

In review mode, long press "Review Button", then short press to confirm deletion after the "Delete" icon appears.

Review Button (Review/Delete)

In observation mode, short press "Enter Review"

In review mode, short press "Exit Review"

In review mode, long press to display "Delete" icon

If a new storage card is inserted and formatting information appears, long press "Confirm Card Formatting"

Capture Button (Capture/Record)

In observation mode, short press "Capture"

In observation mode, long press "Record"

Short press to end recording

In review mode, short press "Exit Review"

Up-button (Zoom Out/ Adjust Light Brightness/ Previous Image)

In observation mode, short press "Zoom Out"

In observation mode, long press "Decrease Light Brightness"

In review mode, short press "Previous Image"

Down-Button (Zoom In/ Adjust Light Brightness/ Next Image)

In observation mode, short press "Zoom In"

In observation mode, long press "Increase Light Brightness"

In review mode, short press "Next Image"

Charging Indicator Light: When charging, the indicator light is solid red, and when fully charged, it shows solid green.

Reset Hole: In case of abnormal freezing of the microscope, use a fine-pointed object to poke this hole to force shutdown.

TF Card Slot: Supports a maximum of 64GB memory card, please use C10 or above high-speed cards.

Charging Port: Supports charging and data transmission.

MODEL INTRODUCTION

This device is divided into 3 modes:

Device Observation Mode: Connect to a computer for simultaneous charging and usage.

Memory Card Reading Mode: Connect to a computer for TF card reading, writing, and formatting.

Computer Observation Mode: Connect to a computer and use through computer software for a more intuitive large-screen experience.

1. Device Observation Mode:

Connect the microscope to the computer via USB data cable, select Device Observation Mode, then press the confirm button, to use the device while charging.

2. Memory Card Reading Mode:

1. This product comes with built-in storage space, capable of storing approximately 100 photos. Insert a personal storage card to shoot videos.

(Photos stored internally cannot be read by other devices for security reasons.)

2. If additional storage is needed, please use a personal storage card (supports up to 64GB).

3. Connect the microscope to the computer via USB data cable, select Memory Card Reading Mode, then press the confirm button.

to view stored photos and videos on the computer (device buttons will be disabled in memory card mode).

3. Computer Observation Mode:

Note: When using Computer Observation Mode

1. Some function buttons on the device will be unavailable, which is normal.

2. In Computer Observation Mode, the device will display a black screen, which is normal and not a product issue.

3. After connection, if the software displays no image, try repeatedly plugging and unplugging the USB data cable or plug the cable into the USB port at the back of the computer.

Windows vista/XP/7/8/10/11 or higher are supported

1. Software installation

1) For WIN 7/8 systems, download and install the AMCAP software.

2) For WIN 10 systems, search directly for the software Windows Camera (Note: Please disable the default laptop camera in Windows! And you must change the camera's privacy settings, which is needed for allowing access.)

3) Or download the application Smart Camera for your computer. Download link: www.inskam.com/download/camera.zip

4) Connect the USB cable supplied with the microscope to the USB port on the back of the computer case. Press and hold the power button to turn on the device and select to enter PC camera mode.

5) Different software is recommended for different Windows systems, please download the appropriate software for your system.

2. Software page display:

1) AMCAP page, as shown below

2) Windows Camera page, as shown below

3) Smart Camera page, as shown below

MacOS systems:

MacOS X 11.0 or higher is supported, not available for Apple laptops with Type-c interface.

2) You can also use the alternative software "Quick Time Player".

CHARGING INSTRUCTIONS

1. Please use 5V 1A power adapter to charge the device.

2. During charging, there will be indication on the microscope panel. When charging is complete, the battery indication is as shown below.

3. After fully charged, the microscope can be used continuously for up to 1.5 hours.

4. After the device is completely dead, it needs to be charged with a 5V/1A charger for at least 1 hour before it can be used normally.

MEMORY CARD AND FORMATTING

⚠ Formatting will delete all data on the card, please proceed with caution!

When inserting a new or incompatible memory card, a formatting prompt may appear.

Long press the review button to confirm formatting. If you do not want to format, please remove the memory card (lightly press the card to eject).

TECHNICAL PARAMETERS

Screen parameters

2.0" IPS

Pixels

2.0 megapixels

Magnification

500X

Image format

JPG

Video format

AVI

Focus mode

Fixed focus (0mm)

Light source

8*LED

Battery capacity

600 mAh

Operating time

1.5 hours

Charging time

1.5 hours

Supported systems

Windows vista/XP/7/8/10/11.
MacOS X 11.0 or higher

TROUBLESHOOTING

Q1: The device cannot be charged.

A1: 1. Replace with a working Type-C data cable.

2. Turn on the main power of the power supply device (e.g., power strip, computer power).

Q2: The device is frozen.

A2: 1. Press the reset hole on the main unit with a fine needle to force shutdown the device.

Q3: Cannot connect to the computer.

A3: 1. Ensure the data cable is plugged in securely, replace the data cable, or use the original data cable.

2. The microscope main unit is not powered on.

3. Confirm whether the device is correctly set to memory card reading mode.

Q4: Unable to save photos/videos.

A4: 1. If a storage card is inserted, replace it with a personal storage card.

2. If no storage card is inserted, please insert a personal storage card.

3. Format the memory card (Note: Formatting will delete all data on the memory card, please remember to back up in time).

Q5: Images appear blurry.

A5: 1. The microscope has a fixed focal length, with a shallow depth of field, suitable for observing flat objects.